

CROSSWIND TABULATION DATA

Solid Line Sets Apart Crosswind Component Under 8 Knots
Shaded Boxes -- Crosswind Component Over 13 Knots

Student Pilot Limitations : (* SET BY CFI)

* 8 knots maximum crosswind component

* 16 knots maximum total wind speed

Wind Speed	Wind Degree Angle Off Runway Heading							
	10	20	30	40	50	60	70	80
10	1.5	3.5	5	6.5	7.5	8.5	9.5	10
11	2	4	5.5	7	8.5	9.5	10.5	11
12	2	4	6	7.5	9	10.5	11	12
13	2.5	4.5	6.5	8.5	10	11.5	12	13
14	2.5	5	7	9	10.5	12	13.5	14
15	2.5	5	7.5	9.5	11.5	13	14	15
16	2.5	5.5	8	10.5	12.5	14	15	16
17	3	6	8.5	11	13	14.5	16	17
18	3	6	9	11.5	14	15.5	17	17.5
19	3.5	6.5	9.5	12	14.5	16.5	18	18.5
20	3.5	7	10	13	15.5	17.5	19	19.5
21	3.5	7	10.5	13.5	16	18	19.5	20.5
22	4	7.5	11	14	17	19	20.5	21.5
23	4	8	11.5	15	17.5	20	21.5	22.5
24	4	8	12	15.5	18.5	21	22.5	23.5
25	4.5	8.5	12.5	16	19	22	23.5	24.5
26	4.5	9	13	16.5	20	22.5	24.5	25.5
27	4.5	9	13.5	17.5	20.5	23.5	25.5	26.5
28	5	9.5	14	18	21.5	24	26.5	27.5
29	5	10	14.5	18.5	22	25	27.5	28.5
30	5	10.5	15	19.5	23	26	28	29.5
31	5.5	10.5	15.5	20	23.5	27	29	30.5
32	5.5	11	16	20.5	24.5	28	30	31.5
33	5.5	11.5	16.5	21	25	28.5	31	32.5
34	6	11.5	17	22	26	29.5	32	33.5
35	6	12	17.5	22.5	27	30.5	33	34.5